

C.M.I. Control and Monitoring Interface

Software Version 1.30.2



Quick Guide: Mounting and connection Commissioning

Table of contents

Manual version 1.08.1 EN

1. Delivery scope	4
2. Mounting and connection	4
2.1. Connections	4
2.2. Making the connections	5
3. IP-Address	5
3.1 Network with DHCP server (standard)	5
3.2. Network without DHCP server	5
3.3. Fixed IP address	5
4. Access via browser	5
4.1. Access via LAN or port forwarding	5
4.2. Access via C.M.I. web portal https://cmi.ta.co.at	6
5. Resetting and loading of factory settings	9

UVR1611 compatibility information

In order to be able to access the full range of functions, the controller must have at least operating system version A3.25.

1. Delivery scope

The delivery scope of the device includes the following parts:

1 pc. Control and Monitoring Interface C.M.I.

- 1 pc. SD card
- 1 pc. 4-pole plug for the CAN bus
- 1 pc. 3-pole plug for the DL bus
- 1 pc. Brief guide
- 1 pc. 12V power unit (only with model: 01/CMI-NT)

2. Mounting and connection

The C.M.I. can be assembled either with 2 screws on an even surface or with the enclosed rapid mounting to a TS35 DIN rail according to the EN 50022 Standard.



2.1. Connections

Connections are labelled and must not be confused. The following Figure also shows termination on the left (CAN bus).



Power consumption: typically 1.5 W

2.2. Making the connections

Connections must be made in the following sequence

- 1. Connection LAN cable
- 2. Connection CAN bus or DL bus cable
- **3.** Optional: power supply with power unit (positive pole on the internal conductor, earth outside)

The **POWER** LED now has to be green permanently.

3. IP-Address

Access requires an IP address.

3.1 Network with DHCP server (standard)

The network settings are determined **automatically**.

3.2. Network without DHCP server

Direct C.M.I. connection- Windows PC

DHCP must be activated on the PC.PC and C.M.I. automatically gets an IP address this way. This process can take more than 1 minute.

3.3. Fixed IP address

- Create a Text file called fix_ip.txt with the required IP address and UTF-8 encoding in the root directory of the SD card. The content of this file must be only an IP address (example: 192.168.0.10) and "Enter".
- 2. Insert the SD card in the C.M.I.
- **3. During the next start,** the C.M.I. adopts this IP address and deletes the txt file on the SD card.

The network settings must then be configured locally (C.M.I. menu Settings/Ethernet).

The LAN LED now has to flash green or be green permanently.

4. Access via browser

4.1. Access via LAN or port forwarding

- 1. Browser start
- Entry in the address field of the browser: cmi (factory setting, only under Windows) or IP address





Entry "cmi"

Entry IP address (example)

The language in this window depends on the language setting in the PC operating system.

3. Authentication: Entry user name and password

Authentifizierung erforderlich		
0	Geben Sie Benutzernamen und Passwort für http://cmi ein	
Benutzername:	admin	
Passwort:	•••••	
	OK Abbrechen	

The **factory-set** predefined user name is **admin**, the password also **admin**. Confirmation with "**OK**".

The language in this window depends on the language setting in the PC operating system.

4. Now the **menu** of the C.M.I. appears already.

Home CAN bus Schematic Data administratio	on Settings Status	Expert
POWER SD GAN LAN	LEDs Power: OK SD: OK CAN: OK LAN: OK	99 99 91 92 91 22 55 km
		CMI003780 V1.26.2 - B1.06 - H0.100
www.ta.co.at ©2008-2017 Technische Alternative RT GmbH, A	maliendorf Roberto	

The additional operation is described in the online help 💿 (help.ta.co.at).

4.2. Access via C.M.I. web portal https://cmi.ta.co.at

If you want access via **Internet**, then the C.M.I can be connected via "**"C.M.I. web portal**". The C.M.I. web portal is a server that was set up by Technische Alternative.

1. Select the address https://cmi.ta.co.at and click "Log in" and "Registration".

Home Log in	TECHNISCHE ALTERNATIVE WEBPORTAL
Username/Email Password Stay logged in	900 (66) 911 (20) 912 (20) 924 (20)
Log in Registration Forgotten password	
www.ta.co.at ©2008-2017 Technische Alternative RT GmbH, Amaliendorf	Legal notice

- 2. Completing the registration form and accepting the terms of use
- **3.** After completing registration, an e-mail with an activation link will be sent to the e-mail address used for registration. This process can take up to 30 minutes.
- 4. After clicking the link, the start page of the web portal is displayed already.



- Adding the C.M.I. in the Web portal Selection of the tab "C.M.I.s"
- 6. Selection "Add C.M.I."

C.M.I.s Account management Log out	TECHNISCHE ALTERNATIVE WEBPORTAL
[Add C.M.I.] [Prquest remote maintenance] Search	ME 56 ME 20 ME 20 ME
My C.M.I.s	
< 1 > Serial + Designation	

7. Entry of C.M.I. data

C.M.I.s Account management Log	out	TECHNISCHE ALTERNATIVE WEBPORTAL
		M 98 M M M M M M M
Add C.M.I.		
Serial number:	CMI12345]
Key:	001ABCDE]
My designation:	John Smith]
My description:		
Allow remote maintenance access for superuser:		
Add		
www.ta.co.at ©2008-2017 Technische Al	ternative RT GmbH, Amaliendorf	Legal notice

On the rear of the device is the **serial number** on the rating plate and the **key** on the key label. The key must be entered **without spaces**.



Caution All warranty and guarantee claims become void if the rating plate or key label is removed!

The "**Designation**" helps with the selection of several individual C.M.I.s and is visible in the list of individual C.M.I.s. If service by the **super user** (e.g. Technische Alternative) is to be allowed at **all times**, the appropriate field will be checked.

8. After updating the page, the C.M.I. appears in the list "My C.M.I.s".

C.M.I.s Account management Log out	TECHNISCHE ALTERNATIVE WEBPORTAL
[Add C.M.I.] [Request remote maintenance]	M 66 (H 52 (H 52 (G 54
Search	
My C.M.I.s	
< 1 >	
Serial + Designation number	Anagement Version Connection
CNII003700 B John Smith	🕜 🛃 V: 1.26.2 🥚

Clicking on the serial number takes you to the C.M.I. menu.

```
The additional operation is described in the online help (<u>help.ta.co.at</u>).
```

5. Resetting and loading of factory settings

Briefly pressing the reset key on the rear of the C.M.I. restarts the C.M.I. (reset).

The C.M.I. can also be restarted (reset) by unplugging the CAN bus connection and plugging it back in.

If the reset button is pressed and released while the red LEDs are still illuminated, resets the C.M.I. to factory settings.

Caution: Pressing the reset button until the red LEDs stop being illuminated starts a firmware update with the C.M.I. operation system saved to the SD card. Up to boot sector 1.04, the current firmware in the "UPDATE" folder of the SD card must be called "**CMI.BIN**". From boot sector 1.05 onwards, it must be called "**FIRMWARE.cmi**". You can identify whether the boot sector is 1.05 or above by 4 red LEDs, which begin to glow faintly when the device is started.

We reserve the right to make technical changes.

© 2018

EU Declaration of conformity

	•
Document- Nr. / Date:	TA17021 / 02/02/2017
Company / Manufacturer:	Technische Alternative RT GmbH
Address:	A- 3872 Amaliendorf, Langestraße 124
This declaration of conform	ity is issued under the sole responsibility of the manufacturer.
Product name:	C.M.I.
Product brand:	Technische Alternative RT GmbH
Product description:	Control and Monitoring Interface
The object of the declaration	n described above is in conformity with Directives:
2014/35/EU	Low voltage standard
2014/30/EU	Electromagnetic compatibility
2011/65/EU	RoHS Restriction of the use of certain hazardous substances
Employed standards:	
EN 60730-1: 2011	Automatic electrical controls for household and similar use – Part 1: General requirements
EN 61000-6-3: 2007 +A1: 2011 + AC2012	Electromagnetic compatibility (EMC) - Part 6-3: Generic standards - Emission standard for residential, commercial and light-industrial environments
EN 61000-6-2: 2005 + AC2005	Electromagnetic compatibility (EMC) - Part 6-2: Generic standards - Immunity for industrial environments
EN 50581: 2012	Technical documentation for the assessment of electrical and electron- ic products with respect to the restriction of hazardous substances
Desition of CE Joholy On m	

Position of CE - label: On packaging, manual and type label

CE

Issuer:

Technische Alternative RT GmbH A- 3872 Amaliendorf, Langestraße 124

This declaration is submitted by

Schreich Andrews

Dipl.-Ing. Andreas Schneider, General manager, 02/02/2017

This declaration certifies the agreement with the named standards, contains however no warranty of characteristics.

The security advices of included product documents are to be considered.

Guarantee conditions

Note: The following guarantee conditions do not in any way limit the legal right to a guarantee; rather expand your rights as a consumer.

- 1. The company Technische Alternative RT GmbH provides a two-year guarantee from the date of purchase by the end consumer for all the devices and parts which it sells. Defects must be reported immediately upon detection and within the guarantee period. Technical support knows the correct solution for nearly all problems. In this respect, contacting us immediately will help to avoid unnecessary expense or effort in troubleshooting.
- 2. The guarantee includes the free of charge repair (but not the cost of on site fault-finding, removal, refitting and shipping) of operational and material defects which impair operation. In the event that a repair is not, for reasons of cost, worthwhile according to the assessment of Technische Alternative, the goods will be replaced.
- 3. Not included is damage resulting from the effects of overvoltage or abnormal ambient conditions. Likewise, no guarantee liability can be accepted if the device defect is due to: transport damage for which we are not responsible, incorrect installation and assembly, incorrect use, non-observance of operating and installation instructions or incorrect maintenance.
- 4. The guarantee claim will expire if repairs or actions are carried out by persons who are not authorised to do so or have not been so authorised by us or if our devices are operated with spare, supplementary or accessory parts which are not considered to be original parts.
- 5. The defective parts must be sent to our factory with an enclosed copy of the proof of purchase and a precise description of the defect. Processing is accelerated if an RMA number is applied for via our home page <u>www.ta.co.at</u>. A prior clarification of the defect with our technical support is necessary.
- 6. Services provided under guarantee result neither in an extension of the guarantee period nor in a resetting of the guarantee period. The guarantee period for fitted parts ends with the guarantee period of the whole device.
- 7. Extended or other claims, especially those for compensation for damage other than to the device itself are, insofar as a liability is not legally required, excluded.

Legal notice

These assembly and operating instructions are protected by copyright.

Use outside the copyright requires the consent of the company Technische Alternative RT GmbH. This applies in particular to reproductions, translations and electronic media.

