

**Vmin, Vmax:** Minimal resp. maximal allowed flow temperature (limiting the heat curve)

**T+20, T-20:** Nominal flow temperature at +20°C resp. -20°C outdoor temperature (= setting of rise)

**Tabs, Tnorm:** Desired room temperature in lowering resp. heating mode (= parallel translation of heat curve)

**These values have an effect to the heat curve.**

#### Difference temperatures diff1, diff2

The output will be released, when the temperature difference between two set sensors exceeds this value.

The hystereses have an increasing effect.

#### Nominal flow temperature Vsoll


Check value (not changeable), is calculated based on measured temperatures and heat curve.

#### Maximum thermostat function max

Hysteresis has an decreasing effect; switch off increasing **max** and switch on decreasing **max - hysteresis**.

#### Minimum thresholds min1, min2

Hystereses have an increasing effect; switch on increasing **min + hysteresis**, switch off decreasing **min**.



#### Mod: Switching over modes

**Aut** - automatic mode

**nor** - holds heating mode at Tnorm, without time function

**AbS** - holds lowering mode at Tabs, without time function

**PAr** - Party function

**FEI** - Holiday function

**UrL** - Vacation function

**Stb** - Standby (frost protection)

#### Par: Parameter input to modes

**Aut**: rAS  $\Rightarrow$  T6 is used as room sensor RAS  
Std  $\Rightarrow$  T6 is no room sensor, frost protection keeps active over T5

Unb  $\Rightarrow$  T6 no room sensor, no frost protection

**nor**: no parameters

**AbS**: no parameters

**PAr**: Setting the time, at which automatic mode should start again

**FEI**: Day of input operates as Saturday, input of days - operate as Sunday

**UrL**: Input length of vacation in days (lowering mode)

**Stb**: Input of frost protection threshold at T5 (Decreasing causes lowering mode)

#### Ausgang: Selection of output by auf/ab

Switch over from **automatic** to **manual** mode (Aut/EIN/Aus = automatic/on/off) by simultaneous pressing the keys „**Eingabe**“ and „**auf**“ or „**ab**“

**Mischer:** Switching over mixer control between **Automatic** and „**Hand**“ (=manual mode) by simultaneous pressing the keys „**Eingabe**“ and „**auf**“ or „**ab**“.

#### Zeitprog: Input of maximal 5 time programs with each 3 switch on and switch off points.

**Tag ZP  $\Rightarrow$  A:** Allocation of time programs set under “Zeitpr” to weekdays and outputs  
**Description of time programs see page 2.**

**Uhr:** Setting of actual time in 10 minutes increments

**Prog:** Selection of the program number according to the chosen diagram. Setting by the blue keys **ab/auf** (down/up)

**Menü:** Setting of additional parameters in sub menus  
**Description of sub menus see page 2**

**Vers.:** Software version of the controller

# Menu HZR 65 Vers. P5.6

