


# Basic control level UVR63H Vers. 7.5 Heating controller



**Set time**

Hours or minutes flash ready for entry  
Switch between hours/minutes  
Change hours/minutes  
Accept time

**Temperature room sensor**

If the room sensor RAS02 is used, then it is important that the type is set to S1 RAS in the sensor menu. Only then can the switch position of the room sensor (operating mode) be correctly processed.  
  
Note in respect of incorrectly set sensor type: The correct temperature is only displayed in automatic operation. Other switch positions show excess temperatures.

**Temperature outside**

The nominal flow temperature is calculated using the external temperature and on the basis of the heat curve.

**Temperature flow**

Display of the flow temperature in °C. In the ideal case the measured value matches the nominal value NP. If TP < NP the mixer is opened, if TP > NP the mixer is closed.

**Calculated nominal flow temperature**

The nominal flow temperature is calculated based on the heating curve and the measured external temperature. The heating circuit controller attempts to reach this temperature at the flow sensor TP through mixer OPEN / CLOSED.

**Temperature inputs 4 - 6**

The sensor inputs S4-S6 are allocated dependent on the program. T4, T5 and T6 therefore indicate the actual measured temperature as long as the inputs have been allocated.  
If the sensor is not connected, the display indicates: 999°C  
Values of external sensors, which are read-in via the data link. Only active inputs are displayed.  
ERR means that no valid value has been read. In this case the external value is set to 0.

**Notes on sensor installation**  
The room sensor should be installed in the reference room not near to a source of heat or near a window.  
The external temperature sensor should be mounted on the coldest wall side some two meters above ground. Temperature influences from nearby air ducts, open windows, etc., should be avoided as far as possible.

## TIME PROGRAM

**Menu for entering the time program**

Set time programs

**Shift worker time program**  
With this it is possible to create several time programs with differing heating periods and to specifically enable time windows simply by setting the parameters SWP. With a combination of programs 1 to 4 with 5 TIMEP1 to 4 are the programs during shift working and TIMEP5 is envisaged for the weekend.

**Time programs P1-P5**

Select time program 1  
Allocation of time program 1 to Monday

Select days MO - SU  
Switches ON or OFF  
confirm and select the next day

After the SU week day allocation, time windows 1-3 follow with nominal value entry

Set switch-on times 1 - 3  
For each time program (P1-P5) there are 3 time windows with possible nominal value allocations available. (Comparable with analog time switch with 5 time selection discs, each with 6 flag pins).

Change hours, Change minutes, confirm

**Rate time (max. 255 min)**

Change nominal value, confirm

**Date**

Display date

Change day, Change month

Display year

Change year, confirm

Automatic summer/winter (standard) time changeover

**OPTIONAL DISPLAYS (after T6 or ext. sensors)**

**Volume flow**

Volume flow, shows the flow rate of the volume flow encoder in litres per hour

**Current Speed stage**

This display only appears if pump speed control (PSC) is activated. The currently output speed stage is indicated (example 26).

**Current analogue level**

This display only appears when the control output is activated. The currently output analog value is displayed (example: 14 = 1.4V or 14% (PWM))

**Current volume flow**

Volume flow [l/h] which is used to calculate the heat quantity. The value here can be either a fixed value (l/h with activated pump output) or a measurement from a volume flow encoder.

**Current power**

The currently determined power equals 10.2 kW. This value is calculated from the flow temperature, return temperature and volume flow in the heat quantity counter.

**Counted heat quantity in MWh**

Total heat quantity in MWh

**Counted heat quantity in kWh**

Total heat quantity in kWh

**Status heating circuit controller**

**Status display**  
Heating controller:  
NORM = normal mode  
LOW = lowering mode  
STB = standby  
MALF = malfunction  
FRO = frost protection mode

**Mode heating circuit controller**

**Operating mode**  
Heating controller  
AUTO = automatic mode  
NORMAL = normal mode  
LOWER = lowering mode  
PARTY = party mode  
LEAVE = vacation mode  
HOLID = national holiday  
STB = standby

**Additional parameter for mode (partially hidden)**

These additional settings are partially hidden. Example: Party mode up to 02.30 h  
AUTO =hidden  
NORMAL=hidden  
PARTY =party until P XX.XX h  
LEAVE=holiday until date M XX XX  
HOLID=holiday until date M XX XX  
STB =hidden

**Required room temperature in lowering mode**

Nominal value lowering mode flashes ready for entry  
Change nominal value  
Accept value

**Required room temperature in normal operation**

Nominal value normal mode flashes ready for entry  
Change nominal value  
Accept value

**Menu for entering the time program**

For selection of the time programs P1-P5, of the shift working program, the rate time and the day-date

**Access the parameter menu**

Access the parameter menu  
Further settings see page 2

**Access the main menu**

Access the menu "Men"  
Further settings see page 2


**Display of the active switch-off conditions of the heating pump**

All display segments are momentarily displayed when the device is started up.

After startup the type designation and the version number are again shown in the display. This gives information about the device intelligence (important for support queries).

The factory setting is loaded by pressing button during plugging in. The following appears on the display: (Load factory setting)

# PARAMETER MENU (required settings & heat curve)



# Main menu (Mixer settings, Switch-off conditions,...)

